



4π systeme
Gesellschaft für Astronomie und Informationstechnologie mbH

TCI

Telescope Control Interface

*Specifications of the Interface to the Telescope Hardware's
Control Software (TCS)*

Version 1.4

Document Id:

4PI-DOC-03-008-02-2

Michael Ruder, Daniel Plasa, Peter Kroll

Revision 464 as of 19th November 2003 (michael)

Revision History:

29.11.2002	Initial Version (alpha) (dp)
05.12.2002	Prefinal Version (dp, pk)
06.12.2002	Finalized Version 1.1 (dp, rs:fe)
25.03.2003	English Version 1.2 with TPL specific parts removed (mr)
14.07.2003	Updated to 1.3, included DIMM interface, pointing and refraction (dp)
08.11.2003	Updated to 1.4, added sensors, RS errors, POINTING now undocumented (mr)

©2002-2004 by 4π systeme, all rights reserved.

\$Id: TCI.tex 464 2003-11-19 15:39:51Z michael\$

Contents

1	Preface	1
2	Basics	1
3	List of Modules	1
3.1	Core Modules	1
3.2	Additional Modules	1
3.3	Module AXIS	2
3.4	Module CABINET	4
3.4.1	RS Style specific Cabinet features	6
3.4.2	RP Style specific Cabinet features	8
3.5	Module CONFIG	9
3.6	Module DEROTATOR	10
3.7	Module DOME	12
3.7.1	Classic DOME features	13
3.7.2	Fold DOME features	14
3.8	Module FILTER	14
3.8.1	Discrete index filters	15
3.8.2	Continuous position filters	15
3.9	Module FOCUS	16
3.10	Module GPS	17
3.11	Module SENSOR	18
3.12	Module TRAJECTORY	19
A	Coordinate Systems of the Telescope Axes	21
B	List of RS Error Symbols	23
C	Undocumented Modules	32
C.1	Module POINTING	32
C.1.1	Pointing model parameters	33
C.1.2	Refraction parameters	34
C.2	Module SIMPLE_FOCUS	34
D	Abbreviations	34
	References	35

1 Preface

This document covers the interface to the telescope control software (TCS) running on the computer in the control cabinet. For the communication the protocol “TPL2” is used (refer to [1]).

2 Basics

- The TCI will include a list of modules which will give an ordered, hierarchical access to all important functions.
- For debugging and problem analysis there will also be modules which give access to internal settings, like controller settings, cabinet switches etc.
- In addition to the TCI core modules there may be one or more additional modules covering your ordered software. These modules will be covered in a separate document.

3 List of Modules

3.1 Core Modules

The following modules are provided by the current version of the TCS:

Name	Function
AXIS[]	Control over the telescope axes. Usually an array of two (for azimuth and zenith distance)
CABINET	Everything that is related to the control cabinet
CONFIG	Configuration parameters and information (like the telescope mount type etc.)
DEROTATOR	Control over the image derotator
FOCUS	Control over the focus motor
GPS	Access to the GPS receiver for time and location data
SENSOR[]	Any sensors (temperatures, pressure)
TRAJECTORY	Module for transferring and running trajectories

3.2 Additional Modules

The following modules can be provided as an option.

Name	Function
CAMERA []	Access to camera(s) [only as an option]
COVER []	Any covers that can be controlled (like mirror covers)
DEROTATOR []	Control over image derotator(s) (i.e. support for multiple derotators)
DOME	Control over the dome
FILTER []	Control over the filter wheel(s) (i.e. support for multiple wheels)
FOCUS []	Control over more than one focus motor
MIRROR	Mirror parameter (e.g., control of a flip mirror)
SWITCH []	Any switches (pumps etc.)
WEATHER []	Access to weather station(s)

Some of the modules are defined as an array (shown as []) to allow multiple instances. If only one instance is available, the module will not be defined as an array.

3.3 Module AXIS

With this module array (typically with 2 elements, azimuth and zenith distance) a low level control to the telescope axes is provided. It is mainly for monitoring and maintenance tasks, as it will not provide functions for precise tracking. For this task, the module `TRAJECTORY` (see section 3.12) should be used which allows a synchronized movement of both telescope axes and the derotator axis.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
DEVICEID	STRING	RO	Hardware device identifier, unique for all TCI devices
POWER	INT	RW	Switch power for this component (0=off, 1=on). The main power (<code>CABINET.POWER</code>) has to be turned on to enable or disable power for single components, otherwise this command will fail

3.3 Module AXIS

Name	Type	Access	Description
POWER_STATE	INT	RO	Power state of the component (0=off, 1=on)
REFERENCED	INT	RO	Referenced state of this component (0=not referenced, 1=referenced)
REALPOS	FLOAT	RO	True current position in degrees. For azimuth, zero will be in the south (northern hemisphere) resp. north (southern hemisphere). The degrees are counted south to west. For zenith distance, zero will be in the zenith, 90 at the horizon (looking to the south if the azimuth is zero), -90 in the opposite direction (if the telescope supports movement through the zenith). (See appendix A for an explanation of the coordinate systems). With the properties !MIN and !MAX the accessible range of positions can be inquired.
CURRPOS	FLOAT	RO	Current position in degrees, corrected by the given OFFSET (in the same unit as REALPOS).
TARGETPOS	FLOAT	RW	The position the telescope is currently moving to (in the same unit as REALPOS). While a trajectory is executed, the variable will constantly be updated to the current position on the trajectory. By writing to this variable, the telescope will switch into direct positioning mode, cancelling a possibly running trajectory (see section 3.12). The callback function will return after the position has been reached so the execution of this command may take a while.
TARGETDISTANCE	FLOAT	RO	The distance between CURRPOS and TARGETPOS.

Name	Type	Access	Description
OFFSET	FLOAT	RW	Additional offset (in the same unit as REALPOS) that will be added to <i>all</i> positioning requests for that component if CABINET.OFFSET_MODE is not 0. This can be used for a guiding system. It will also be used to implement the manual movement with an optional bottle if CABINET.OFFSET_MODE is 2.
CURRSPEED	FLOAT	RO	The current speed of the axis in degree per second
CURRACC	FLOAT	RO	The current acceleration in degree per second squared.

The following axis types are currently defined:

Type no	Description
0	Not connected (since a telescope needs at least two axes, this should not occur)
1	Standard TCI Axis
2	Standard TCI Axis, V2, which includes direct trajectory support (planned)

3.4 Module CABINET

This module allows direct access to the control cabinet and provides functions for turning on and off main power as well as a lot of diagnostic functions.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below.
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality.
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality.

3.4 Module CABINET

Name	Type	Access	Description
POWER	INT	RW	Switch main power on or off (0=off, 1=on). Individual components can be turned on and off as long as main power has been turned on with the respective POWER variable of the component. After turning on main power all components will be powered on automatically.
POWER_STATE	INT	RO	Main power state (0=off, 1=on, -1=emergency stop). The power state of individual components can be checked with the respective POWER_STATE variable of the component.
REFERENCED	INT	RO	All powered drives referenced (0=not all referenced, 1=all referenced, -1=referencing in progress). The referenced state of individual components can be checked with the respective REFERENCED variable of the component.
OFFSET_MODE	INT	RW	Consideration of the additional offset for all components (0=offset will be ignored, 1=offset will be used, 2=offset will be used and can be modified with the optional bottle)
TIME	FLOAT	RO	Precision time source of the real time core. This is the time used for executing trajectories. The format is seconds since January 1st, 1970 UTC in millisecond resolution.

The following axis types are currently defined:

Type no	Description
0	No type (this should not occur)
1	RS Style Control Cabinet
2	RP Style Control Cabinet

There are several other internal variables available, mostly for identifying the hardware or debugging and maintenance tasks. These are however strongly TYPE specific.

3.4.1 RS Style specific Cabinet features

Name	Type	Access	Description
MODE	INT	RO	Control cabinet mode (0=local, no remote (TPL) access, 1=remote, TPL controlled, -1=no operation possible).
MANUAL_CONTROL	STRUCT	—	Information about the optional bottle for manual control (see below)
VERSION_TEXT	STRING	RO	Concatenated string of all version identifiers of the used components
HW_ID	STRING	RO	Unique hardware ID of the cabinet
SW_ID	STRING	RO	Unique ID of the low level driver software running on the cabinet computer
SW_VERSION	STRING	RO	Version of the low level driver software
CONFIG_ID	STRING	RO	Unique hardware ID of the control components mounted on the telescope
PARAM_ID	STRING	RO	Unique ID for the current set of parameters for the low level driver software
PARAM_VERSION	STRING	RO	Version of the current parameter set
PARAM_NAME	STRING	RO	Name of the current parameter set
LOG []	STRUCT	—	Structure array with contents of driver log files (see below)
STATUS	STRUCT	—	Structure allowing access to driver status/error flags (see below)
RTCORE	MODULE	—	Module allowing access to internal driver variables (see below)
DEBUG	STRUCT	—	Structure for realtime debugging information (see below)

The `CABINET.MANUAL_CONTROL` structure gives access to informations and settings of the optional bottle.

Name	Type	Access	Description
MODE	INT	RO	Bottle state (0=turned off, 1=turned on)
BUTTONLIGHT	FLOAT	RW	Brightness of bottle buttons (0=lowest, 1=brightest)

The `CABINET.LOG []` structure array allows the readout of the logfiles created by the realtime core.

3.4 Module CABINET

Name	Type	Access	Description
NAME	STRING	RO	Name of the log file
FILE	STRING	RO	The entire log file contents as one string

The `CABINET.STATUS` structure allows a readout of the driver status and error flags. These flags can also be reset.

Name	Type	Access	Description
STATUS	INT	RW	Current status of the system (0=everything ok, 1=warning, 2=stop, 3=panic) / Reset all errors on write
LATCH	STRING	RO	Error latch bit field (transmitted as hex string). If an error occurs, even if it vanishes before readout of the <code>CURRENT</code> variable, the corresponding bit will stay set in this variable until it is reset by writing to <code>STATUS</code>
LATCH_COUNT	INT	RO	Number of set bits in the <code>LATCH</code> register
CURRENT	STRING	RO	Bit field (transmitted as hex string) showing all currently active errors
SYMBOLS[]	STRING	RO	Contains a symbol for each bit in the <code>LATCH</code> and <code>CURRENT</code> registers. The bits are numbered (starting with 0) in the hex strings from right (the lowest bits first) to left. For an explanation of all possible errors, refer to appendix B.

The `CABINET.RTCORE` module gives read-only access to the internal states of the realtime core.

Name	Type	Access	Description
DLG_STATE	INT	RO	Internal state of the dialog process
RTM_STATE	INT	RO	Internal state of the realtime process
RSVARS[]	STRUCT	—	Access to all internal parameter variables (see below)

The `CABINET.RTCORE.RSVARS[]` structure array allows read-only access to all internal variables of the realtime core.

Name	Type	Access	Description
NAME	STRING	RO	Name of the parameter
VALUE	STRING	RO	Value of the parameter

Name	Type	Access	Description
DESCRIPTION	STRING	RO	Description of the parameter
UNIT	STRING	RO	Unit of the parameter

The `CABINET.DEBUG` structure allows recording of realtime debugging information

Name	Type	Access	Description
DO_TRACE	INT	RW	Starts the recording of the given number of traces. Each trace has 4000 points and every point is <code>TRACE_DELAY</code> milliseconds apart. The traces are written to the flash disk of the TCC. By reading this variable, the remaining number of traces can be acquired.
TRACE_DELAY	INT	RW	The delay in milliseconds between two points of a trace.
TRACE_SPACE	INT	RO	The free space in kilobytes on the flash disk of the TCC.
OSZI_CHANNEL	INT	RW	Allows the selection of the channel for the oszi functionality. Each channel represents a fixed group of variables that are to be monitored.

3.4.2 RP Style specific Cabinet features

Name	Type	Access	Description
INIT	INT	WO	Writing a value of 1 forces the telescope to re-initialialize all axes. A value of 0 re-initializes only axes that are not initialized (possibly due to a emergency stop).
VERSION_TEXT	STRING	RO	Concatenated string of all version identifiers of the used components
HW_ID	STRING	RO	Unique hardware ID of the cabinet
SW_ID	STRING	RO	Unique ID of the low level driver software running on the cabinet computer
SW_VERSION	STRING	RO	Version of the low level driver software
CONFIG_ID	STRING	RO	Unique hardware ID of the control components mounted on the telescope
PARAM_ID	STRING	RO	Unique ID for the current set of parameters for the low level driver software

3.5 Module CONFIG

Name	Type	Access	Description
PARAM_VERSION	STRING	RO	Version of the current parameter set
PARAM_NAME	STRING	RO	Name of the current parameter set
STATUS	MODULE	—	Module allowing access to driver status/error flags (see below)
CORE	MODULE	—	Module allowing access to internal driver variables (see below)

The `CABINET.STATUS` module allows a readout of the driver status and error flags. These flags can also be reset.

Name	Type	Access	Description
STATUS	INT	RW	Current status of the system (0=everything ok, 1=warning, 2=stop, 3=panic) / Reset all errors on write
LATCH	STRING	RO	A string with all occurred errors numbers separated by blanks.

The `CABINET.CORE` module gives read-only access to the internal states of the realtime core and the parameter set.

Name	Type	Access	Description
UPTIME	INT	RO	Uptime of the core control in seconds
EW[]	STRUCT	—	Access to all internal parameter variables
EW[] .NAME	STRING	RO	Name of the parameter
EW[] .VALUE	STRING	RO	Value of the parameter

3.5 Module CONFIG

This module is used to gather configuration information about the telescope in general. Currently only the telescope mount type can be inquired.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below

The following telescope (mount) types are currently defined:

Type no	Description
0	No telescope (very unusual...)
1	Alt-Azimuth mount, capable of moving through the zenith

Type no	Description
2	Alt-Azimuth mount, not capable of moving through the zenith

3.6 Module DEROTATOR

This module (or, optionally, module array) allows direct control of the derotator(s). This is mainly for monitoring and maintenance tasks, as it will not provide functions for precise movement during tracking. For this task, the module TRAJECTORY (see section 3.12) should be used which allows a synchronized movement of the derotator axes with both telescope axes.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
DEVICEID	STRING	RO	Hardware device identifier, unique for all TCI devices
POWER	INT	RW	Switch power for this component (0=off, 1=on). The main power (CABINET.POWER) has to be turned on to enable or disable power for single components, otherwise this command will fail
POWER_STATE	INT	RO	Power state of the component (0=off, 1=on)
REFERENCED	INT	RO	Referenced state of this component (0=not referenced, 1=referenced)

3.6 Module DEROTATOR

Name	Type	Access	Description
REALPOS	FLOAT	RO	True current position in degrees. Zero will be on the upper side (when looking toward the flange.) The degrees are counted in the same direction as for the zenith distance (Type 1 and 3) or in the same direction as for the azimuth (Type 2 and 4) or in mathematical positive direction (Type 5) Refer to appendix A for an explanation of the coordinate systems and possible derotator locations). With the properties !MIN and !MAX the allowed range of positions can be inquired.
CURRPOS	FLOAT	RO	Current position in degrees, corrected by the given OFFSET (in the same unit as REALPOS).
TARGETPOS	FLOAT	RW	The position the derotator is currently moving to (in the same unit as REALPOS). While a trajectory is executed, the variable will constantly be updated to the current position on the trajectory. By writing to this variable, the telescope will switch into direct positioning mode, cancelling a possibly running trajectory (see section 3.12). The callback function will return after the position has been reached so the execution of this command may take a while.
TARGETDISTANCE	FLOAT	RO	The distance between CURRPOS and TARGETPOS.
OFFSET	FLOAT	RW	Additional offset (in the same unit as REALPOS) that will be added to <i>all</i> positioning requests for that component if CABINET.OFFSET_MODE is not 0. This can be used for a guiding system. It will also be used to implement the manual movement with the supplied paddle if CABINET.OFFSET_MODE is 2
CURRSPEED	FLOAT	RO	The current speed of the derotator in degree per second

Name	Type	Access	Description
CURRACC	FLOAT	RO	The current acceleration in degree per second squared.

The following derotator types are currently defined:

Type no	Description
0	Not connected
1	Standard TCI derotator on focus 1
2	Standard TCI derotator on focus 2
3	Standard TCI derotator on focus 3
4	Standard TCI derotator on focus 4
5	Standard TCI derotator on focus 5
6	Standard TCI derotator on focus 1, V2, which includes direct trajectory support (planned)
7	Standard TCI derotator on focus 2, V2, which includes direct trajectory support (planned)
8	Standard TCI derotator on focus 3, V2, which includes direct trajectory support (planned)
9	Standard TCI derotator on focus 4, V2, which includes direct trajectory support (planned)
10	Standard TCI derotator on focus 5, V2, which includes direct trajectory support (planned)

3.7 Module DOME

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
DEVICEID	STRING	RO	Hardware device identifier, unique for all TCI devices
POWER	INT	RW	Switch power for this component (0=off, 1=on). The main power (CABINET.POWER) has to be turned on to enable or disable power for single components, otherwise this command will fail

Name	Type	Access	Description
POWER_STATE	INT	RO	Power state of the component (0=off, 1=on)
REFERENCED	INT	RO	Referenced state of this component (0=not referenced, 1=referenced)

The following dome types are currently defined:

Type no	Description
0	Not connected
1	Classic dome with slit position.
2	Fold enclosure. Either open or closed.

Depending on the TYPE the following functions are defined:

3.7.1 Classic DOME features

Name	Type	Access	Description
REALPOS	FLOAT	RO	True current position of the slit in degrees. Same meaning as with the azimuth axis. With the properties !MIN and !MAX the allowed range of positions can be inquired.
CURRPOS	FLOAT	RO	Current position in degrees, corrected by the given OFFSET.
TARGETPOS	FLOAT	RW	The position slit is currently moving to (in the same unit as REALPOS). By writing to the variable, the slit will start positioning. The callback function will return after the position has been reached so the execution of this command may take a while.
TARGETDISTANCE	FLOAT	RO	The distance between CURRPOS and TARGETPOS.
OFFSET	FLOAT	RW	Additional offset (in the same unit as CURRPOS) that will be added to <i>all</i> positioning requests for that component if CABINET.OFFSET_MODE is not 0. This can be used for a guiding system. It will also be used to implement the manual movement with the supplied paddle if CABINET.OFFSET_MODE is 2
CURRSPEED	FLOAT	RO	The current speed in degree per second

Name	Type	Access	Description
CURRACC	FLOAT	RO	The current acceleration in degree per second squared.
ENCLOSURE_STATE	FLOAT	RO	Current position of the slit enclosure. Since the Slit does not have an encoder, this will be 0 if it is open, 1 if it is closed and 0.5 if somewhere in between.
ENCLOSURE	INT	RW	The position the slit enclosure is currently moving to (as defined with ENCLOSURE_STATE). By writing to the variable, the slit will open or close.

3.7.2 Fold DOME features

Name	Type	Access	Description
ENCLOSURE_STATE	FLOAT	RO	Current position. Since the dome does not have an encoder, this will be 0 if it is open, 1 if it is closed and 0.5 if somewhere in between.
ENCLOSURE	INT	RW	The position the dome is currently moving to (as defined with ENCLOSURE_STATE). By writing to the variable, the dome will open or close.

3.8 Module FILTER

This module (or, optionally, module array) provides functions to move the filter wheel(s) and select the filters by index.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
DEVICEID	STRING	RO	Hardware device identifier, unique for all TCI devices

Name	Type	Access	Description
POWER	INT	RW	Switch power for this component (0=off, 1=on). The main power (<code>CABINET.POWER</code>) has to be turned on to enable or disable power for single components, otherwise this command will fail
POWER_STATE	INT	RO	Power state of the component (0=off, 1=on)
REFERENCED	INT	RO	Referenced state of this component (0=not referenced, 1=referenced)

The following filter types are currently defined:

Type no	Description
0	Not connected
1	Filter wheel with discrete index numbers
2	Filter wheel with continuous positions

3.8.1 Discrete index filters

For filters with discrete positions, the following functions will additionally be provided:

Name	Type	Access	Description
CURRINDEX	INT	RO	Currently selected filter number. With the properties <code>!MIN</code> and <code>!MAX</code> the allowed range of positions can be inquired.
TARGETINDEX	INT	RW	The filter number the wheel is currently turning to. By writing to the variable, the filter wheel will start to move towards the selected filter. The command will be completed once the position has been reached.
TARGETDISTANCE	INT	RO	The distance between <code>CURRINDEX</code> and <code>TARGETINDEX</code> .

3.8.2 Continuous position filters

For filters with continuous positioning (e.g., polarization filters) instead the following functions are provided:

Name	Type	Access	Description
REALPOS	FLOAT	RO	True current filter wheel position in degrees. With the properties !MIN and !MAX the allowed range of positions can be inquired.
CURRPOS	FLOAT	RO	The current filter wheel position in degrees, corrected by the given OFFSET.
TARGETPOS	FLOAT	RW	The position the wheel is currently turning to (in the same unit as REALPOS).
TARGETDISTANCE	FLOAT	RO	The distance between REALPOS and TARGETPOS.
OFFSET	FLOAT	RW	Additional offset (in the same unit as REALPOS) that will be added to <i>all</i> positioning requests for that component if CABINET.OFFSET_MODE is not 0. This can be used for a guiding system. It will also be used to implement the manual movement with the supplied paddle if CABINET.OFFSET_MODE is 2.

3.9 Module FOCUS

This module (or, optionally, module array) provides functions to move the focus motor(s).

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
POWER	INT	RW	Switch power for this component (0=off, 1=on). The main power (CABINET.POWER) has to be turned on to enable or disable power for single components, otherwise this command will fail. If the power is turned off and the focus motor has a brake, it will automatically come on.
POWER_STATE	INT	RO	Power state of the component (0=off, 1=on)

Name	Type	Access	Description
REFERENCED	INT	RO	Referenced state of this component (0=not referenced, 1=referenced)
REALPOS	FLOAT	RO	True current position in millimeter. Smaller values mean a smaller distance between primary and secondary mirror. Zero is the hardware limited, smallest distance between these two mirrors. With the properties !MIN and !MAX the allowed range of positions can be inquired.
CURRPOS	FLOAT	RO	Current position in millimeter.
TARGETPOS	FLOAT	RW	The position the focus motor is currently moving to (in the same unit as REALPOS). By writing to the variable, the focus motor will start to move towards this position. The command will be completed once the position has been reached.
TARGETDISTANCE	FLOAT	RO	The distance between CURRPOS and TARGETPOS.
OFFSET	FLOAT	RW	Additional offset (in the same unit as REALPOS) that will be added to <i>all</i> positioning requests for that component if CABINET.OFFSET_MODE is not 0. It will be used to implement the manual movement with the supplied paddle if CABINET.OFFSET_MODE is 2
CURRSPEED	FLOAT	RO	The current speed of the focus motor in millimeter per second

The following axis types are currently defined:

Type no	Description
0	Not connected
1	Focus motor with brake system
2	Focus motor without brake system

3.10 Module GPS

With this module, access to the GPS receiver is possible. Time and position information can be acquired. The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
TIME	STRING	RO	Date and time as Unix formatted text string (as received by the GPS receiver, second resolution only)
POS	STRUCT	—	Structure with the GPS Position (see below)

The following GPS types are currently defined:

Type no	Description
0	Not connected
1	HOPF GPS system (no height information available, will always be zero)

The `GPS.POS` structure gives access to the GPS position from the receiver.

Name	Type	Access	Description
LAT	FLOAT	RO	Latitude in degrees
LON	FLOAT	RO	Longitude in degrees
HEIGHT	FLOAT	RO	Height in meters (if provided by the receiver, otherwise zero)

3.11 Module SENSOR

This module array provides access to all temperature, pressure etc. sensors of the telescope.

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
VALUE	INT	RO	Sensor value in the unit specified for the type (see below)

The following sensor types are currently defined:

Type no	Description
0	Not connected
1	Temperature, unit °C
2	Pressure, unit Pa
3	Flow, unit $\frac{m^3}{s}$

3.12 Module TRAJECTORY

This module allows movement of both telescope axes and the derotator axis. In contrast to the **AXIS** modules (section 3.3) and the **DEROTATOR** module(s) (section 3.6) all axes will be moved synchronously and will reach the given positions exactly at the given times. Therefore a highly precise tracking is possible. Furthermore, a spline interpolation is done between the given sample points to make the movement smoother.

If the **CABINET.OFFSET_MODE** is not 0, the offsets set for both axes and the derotator will be applied to the trajectory points. It is possible to change the offsets during trajectory execution, allowing f.e. to center a tracked star.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Spline engine version. Newer version may introduce new functionality
REVISION	STRING	RO	Spline engine revision. Newer revision will not introduce new functionality
BUFFER[]	STRUCT	—	Struct array which is used as buffer for new sample points (see below)
FREEBUFFER	INT	RO	Depending on the TYPE this is the number of entire buffers that can be added by GENERATE without blocking (TYPE 1) or the number of sample points in the buffer that can be added without blocking (TYPE 2).

Name	Type	Access	Description
GENERATE	INT	WO	Generates a spline of the first n sample point entries of the <code>BUFFER</code> , where n is the number written to the variable and adds this new spline to the internal trajectory buffer. The Callback will only return if all sample points have been written to the trajectory buffer or fail if no buffers are available. Depending on the <code>TYPE</code> this will almost happen instantaneous with <code>TYPE 1</code> and may take some time with <code>TYPE 2</code> (see below).
EXECUTE	INT	RW	By writing 1 to this variable, the execution of the precalculated splines is started. This function will only return if the internal spline buffer is empty or the spline execution was aborted. During the execution, more splines can be generated from new sample points (until the spline buffer is full, see below) to allow continuous tracking over longer periods of time. By setting the variable to 0, the execution is aborted. To check if a trajectory is executing, the variable can also be read, returning 1 or 0.
CLEAR	INT	WO	Clear the entire sample point buffer on writing 1.
RESET	INT	WO	Discard all sample points and splines and stop execution on writing 1.
INTERPOLATION_MODE	INT	RW	Method which is used for the interpolation between sample points (see below).
INTERPOLATION_ORDER	INT	RW	In case of spline interpolation, the maximal order of the used polynoms.

The following trajectory module types are currently defined:

Type no	Description
0	No trajectory support
1	Trajectory support for azimuth, zenith distance and derotator. Buffer data must overlap by at least <code>INTERPOLATION_ORDER</code> data points.

Type no	Description
2	Trajectory support for azimuth, zenith distance and derotator. Buffer need not to overlap.

The struct array for the trajectory buffer has the following entries:

Name	Type	Access	Description
TIME	FLOAT	RW	Time (Seconds since 01.01.1970 with fractions after the decimal point)
AZ	FLOAT	RW	Azimuth position (in degrees, see section 3.3 and A)
ZD	FLOAT	RW	Zenith distance (in degrees, see section 3.3 and A)
DEROT	FLOAT	RW	Derotator position (in degrees, see section 3.6 and A)

The following interpolation modes are currently defined:

Type no	Description
0	No interpolation available.
1	Spline interpolation, INTERPOLATION_ORDER can be used to configure the maximum order of the used polynoms.

A Coordinate Systems of the Telescope Axes

An overview of the coordinate systems on all telescope axes is given in fig. 1.

The top left image shows the telescope from above. The azimuth zero position is in the south (northern hemisphere) or in the north (southern hemisphere). The telescope will look in that direction for a zenith distance of +90 degrees. The azimuth angle is counted clockwise on both hemispheres.

In the top right image one can see a side view of the telescope. To distinguish the two directions of the zenith distance (in case of a telescope capable of moving through the zenith) the telescope chain is used. If the telescope is looking in the same direction as the chain, the zenith distance is defined positive. Zero is always defined to be in the zenith.

The two images in the middle show the derotator as seen when looking toward the flange on the fork. The angle for the derotator is counted in the same direction as for the zenith distance, therefore the direction differs on the both sides. Zero is always defined to be on the top.

The lower image shows the coordinate system for the focus motor. Zero is here

Absolute Instrumental Coordinate Systems




Figure 1: Overview of the coordinate systems on all telescope axes

defined to be the smallest, by hardware restraints, possible distance between both mirrors. The focus position is then always positive, giving the additional distance in millimeters.

B List of RS Error Symbols

The cabinet software uses a bit field to record errors that have occurred. This bit field can be retrieved using `CABINET.STATUS.LATCH` and `CABINET.STATUS.CURRENT` (see section 3.4). The bits are numbered from right (lowest bit) to left. By reading the corresponding array element from `CABINET.STATUS.SYMBOLS[]` it is possible to get a symbolic name of the error. A list of all possible errors together with their number and their meaning is given in the remainder of this section. (To identify an error, only the symbolic name should be used as the number may change in future releases!)

For most errors there is a classification of the severity, as well as a recommendation of what to do, if the error occurs:

Class	Description
[I]	Information message, usually no user intervention necessary.
[W]	Warning message, usually the system will continue to operate, but with some limitations.
[E]	Error message, the whole system is halted and put in a safe condition.
[P]	Panic message, the whole system is halted and put in a safe condition.

Short	Recommendation
(C)	Clear the error, after the reason for the error (f.e. the too large coordinate in case of a soft limit condition) has been resolved.
(R)	If possible, resolve the reason for the error and restart the entire system afterwards. If the error occurs again, ask for support.
(S)	Ask for support, as this error is not supposed to occur in a release version.

Some errors (like the limit switch errors for azimuth and elevation) should never occur during normal operation, and have therefore a “(R)” recommendation. However, when the telescope is moved by hand while the power is off, this error can be cleared without a system reboot.

B LIST OF RS ERROR SYMBOLS

No	Text	Description
0	I_MOD_INIT	(S) Module initialisation, [should never occur]
1	I_MOD_ERR_OVERFLOW	(S) Not all modules logged in the shared memory area [should never occur]
2	E_TEST_ERROR	[E](S) Software test error message [should never occur]
3	W_TEST_WARNUNG	[W](S) Software test warning message [should never occur]
4	E_TEST_PANIK	[P](S) Software test panic message [should never occur]
5	ERR_Main_bad_state	[E](R) Internal software error, wrong state detected
6	ERR_Main_Debug_Mode	[W](R) Internal software error, debug mode
7	ERR_Dlg_not_running	[P](R) The dialog program is not running
8	ERR_Power_ON_OFF	[I] The power was turned on or off in the manual mode
9	ERR_Power	[W](C) The software intentionally turned off the power (CABINET.POWER=0)
10	ERR_EmergencyOff_Fuse_F161	[P](R) Fuse F161 for the emergency off circuit failed
11	ERR_EmergencyOff_A311	[E](C) The emergency off switch was pressed on either the cabinet or the bottle
12	ERR_USV_Power_Lost	[P](C) The uninterruptible power source detected a power failure of main power and took over. Some subsystems, f.e. the ETEL drives, will not be powered by the UPS.
13	ERR_USV_Battery_alarm_G121	[W](R) The uninterruptible power source reported a battery alarm condition
14	ERR_Phase_Watcher_Fuse_F101	[W](R) Fuse F101 of the phase watcher failed
15	ERR_Phase_Watcher_N101	[E](R) The direction of the rotary current is wrong or there was over- or undervoltage detected
16	ERR_Fuse_F122	[P](R) Fuse F122 failed
17	ERR_Bottel_Fuse_F168	[W](R) Fuse F168 for the bottle failed
18	ERR_ETEL_MainPower_Fuse_Q102	[W](R) Fuse Q102 for the main power to the telescope axes failed

No	Text	Description
19	ERR_ETEL_Fan_Fuse_F612	[W](C) Fuse F612 for the cooling fans to the motor controllers failed
20	ERR_climate_control_Fuse_F201	[W](C) Fuse F201 for the cabinet cooling fan failed
21	ERR_cabinet_heating_Fuse_F204	[W](C) Fuse F204 for the cabinet heating system failed
22	ERR_teleskop_socket_Fuse_F205	[W](R) Fuse F205 failed
23	ERR_oil_pump_Fuse_Q411	[W](R) Fuse Q411 for the oil pump failed
24	ERR_oil_extractionpump_Fuse_Q431	[W](C) Fuse Q431 for the oil extraction pump failed
25	ERR_oil_heating_Fuse_Q412	[W](C) Fuse Q412 for the oil heater failed
26	ERR_oil_bad_state	[P](R) Internal software error, wrong state detected
27	ERR_oil_Level	[W](C) Oil level is not okay
28	ERR_oil_Level_low	[W](C) Oil level is too low
29	ERR_oil_Level_high	[W](C) Oil level is too high
30	ERR_oil_Temperature_low	[W](C) Oil temperature is too low
31	ERR_oil_Temperature_high	[W](C) Oil temperature is too high
32	ERR_oil_Filter	[W](C) Oil filter is clogged
33	ERR_oil_Filter_status	[W](C) Oil filter is clogged
34	ERR_oil_Pressure	[W](C) Oil pressure too low during operation
35	ERR_oil_Pressure_TIMEOUT	[W](R) Oil pressure did not reach correct level within the timeout period (during system power on)
36	ERR_cover_Fuse_F165	[W](R) Fuse F165 for the cover motor(s) failed
37	ERR_cover1_bad_state	[P](R) Internal software error, wrong state detected
38	ERR_cover1_TIMEOUT	[W](C) Cover motor 1 did not reach the position within the expected time
39	ERR_cover2_bad_state	[P](R) Internal software error, wrong state detected
40	ERR_cover2_TIMEOUT	[W](C) Cover motor 2 did not reach the position within the expected time
41	ERR_cover3_bad_state	[P](R) Internal software error, wrong state detected
42	ERR_cover3_TIMEOUT	[W](C) Cover motor 3 did not reach the position within the expected time

B LIST OF RS ERROR SYMBOLS

No	Text	Description
43	ERR_astrodome_Fuse_Q451	[W](R) Fuse Q451 for the control of the dome motor(s) failed
44	ERR_astrodome1_bad_state	[P](R) Internal software error, wrong state detected
45	ERR_astrodome1_TIMEOUT	[W](C) Dome motor 1 did not reach the position within the expected time
46	ERR_astrodome2_bad_state	[P](R) Internal software error, wrong state detected
47	ERR_astrodome2_TIMEOUT	[W](C) Dome motor 2 did not reach the position within the expected time
48	ERR_Focus_Fuse_F163	[W](R) Fuse F163 for the focus motor failed
49	ERR_BFocus_bad_state	[P](R) Internal software error, wrong state detected
50	ERR_Focus_bad_state	[P](R) Internal software error, wrong state detected
51	ERR_Focus_CONTR	[W](R) The focus motor controller returned an error
52	ERR_Focus_Referenze	[W](R) The reference mark of the focus drive was not found within the expected time
53	ERR_Focus_LimitSwitch_left	[W](R) The focus drive reached the left hardware limit switch
54	ERR_Focus_LimitSwitch_right	[W](R) The focus drive reached the right hardware limit switch
55	ERR_Focus_Soft_Limit_MAX	[W](C) The given target position for the focus was too large
56	ERR_Focus_Soft_Limit_MIN	[W](C) The given target position for the focus was too small
57	ERR_Derotator_Fuse_F166	[W](R) Fuse F166 for the derotator motor failed
58	ERR_BDerotator_bad_state	[P](R) Internal software error, wrong state detected
59	ERR_Derotator_bad_state	[P](R) Internal software error, wrong state detected
60	ERR_Derotator_CONTR	[W](R) The derotator motor controller returned an error
61	ERR_Derotator_Referenze	[W](R) The reference mark of the derotator drive was not found within the expected time

No	Text	Description
62	ERR_Derotator_LimitSwitch_left	[W](R) The derotator drive reached the left hardware limit switch
63	ERR_Derotator_LimitSwitch_right	[W](R) The derotator drive reached the right hardware limit switch
64	ERR_Derotator_Soft_Limit_MAX	[W](C) The given target position for the derotator was too large
65	ERR_Derotator_Soft_Limit_MIN	[W](C) The given target position for the derotator was too small
66	ERR_color_wheel_Fuse_F164	[W](R) Fuse F164 for the filter wheel failed
67	ERR_color_wheel_bad_state	[P](R) Internal software error, wrong state detected
68	ERR_color_wheel_timeout_drive	[W](R) The filter wheel did not pass the next filter index within the expected time
69	ERR_color_wheel_Referenze	[W](R) The reference mark of the filter wheel was not found within the expected time
70	ERR_color_wheel_Ref_mismatch	[W](R) Wrong count of index marks counted at the reference mark
71	ERR_color_wheel_unreachable	[W](C) The selected filter index was too large
72	ERR_no_Interpolation_Points	[W](C) The trajectory ran out of sample points and therefore, the trajectory execution stopped
73	ERR_Extrapolation_Points	[W](C) ??? The interpolation engine discovered a gap in the sample points and had to extrapolate points
74	ERR_mirror_stop_Fuse_F167	[W](R) ??? Fuse F167 for the mirror stop failed
75	ERR_mirror_stop_bad_state	[P](R) Internal software error, wrong state detected
76	ERR_mirror_stop_TIMEOUT	[W](C) ??? The mirror stop did not reach the position within the expected time
77	ERR_mirror_rotation_Fuse_F168	[W](R) Fuse F168 for the mirror rotator failed
78	ERR_mirror_rotation_bad_state	[P](R) Internal software error, wrong state detected
79	ERR_mirror_rotation_CONTR	[W](R) The mirror rotator controller returned an error

B LIST OF RS ERROR SYMBOLS

No	Text	Description
80	ERR_mirror_rotation_Referenze	[W](R) The reference mark of the mirror rotator was not found within the expected time
81	ERR_mirror_rotation_LimitSwitch_left	[W](R) The mirror rotator reached the left hardware limit switch
82	ERR_mirror_rotation_LimitSwitch_right	[W](R) The mirror rotator reached the right hardware limit switch
83	ERR_mirror_rotation_Soft_Limit_MAX	[W](C) The given target position for the mirror rotator was too large
84	ERR_mirror_rotation_Soft_Limit_MIN	[W](C) The given target position for the mirror rotator was too small
85	ERR_GPS_Uart_TX_Error	[W](C) An error occurred while sending data to the GPS receiver
86	ERR_GPS_Uart_RX_Error	[W](C) An error occurred while reading data from the GPS receiver
87	ERR_GPS_Error	[W](C) Communication error with the GPS receiver
88	ERR_GPS_Satellites_too_few	[W](C) The GPS receiver did not receive enough satellites for locking onto the GPS time during initialisation
89	ERR_GPS_Satellites_lost	[W](C) The GPS receiver lost the lock on the GPS time
90	ERR_GPS_Leap_second	[W](C) There was a leap second announcement received. However, the leap second will not be applied until system restart
91	ERR_Clock_Tes_Error	[W](C) Internal clock error
92	ERR_Clock_Puls_Error	[W](C) Wrong or missing clock pulse from the GPS receiver
93	ERR_Clock_Regulator_Limit	[W](C) The clock regulator was unable to keep the clock within the defined offset to the GPS time
94	ERR_Clock_SysClk_Error	[W](C) Internal system clock error
95	ERR_ETEL_Power_Fuse_F610	[W](R) The Fuse F610 for the main power to the ETEL drives failed
96	ERR_ETEL_Control_Fuse_F611	[W](R) The Fuse F611 for the power to the ETEL motor controllers failed
97	ERR_ETEL_Move_Power_up	[W](C) One ETEL axis was moving during power up

No	Text	Description
98	ERR_ETEL_Profibus_FEHLER	[W](R) The ETEL controller did not answer on the profibus within the expected time
99	ERR_azm_FAULT	[W](C) The azimuth axis controller raised an error message and the axis stopped moving
100	ERR_azm_ALARM	[W](C) The azimuth axis controller raised a warning message but the axis will usually continue moving
101	ERR_azm_TIMEOUT	[W](R) The azimuth axis controller did not respond to a request within the expected time
102	ERR_azm_Ref_FEHLER	[W](R) An error occurred during the referencing process of the azimuth axis
103	ERR_azm_Parm_FEHLER	[W](R) An error occurred during the read-out of needed parameters from the azimuth axis controller
104	ERR_azm_Etel_FEHLER	[W](R) The azimuth axis controller is not in the correct state for the requested operation
105	ERR_azm_bad_state	[P](R) Internal software error, wrong state detected
106	ERR_azm_LimitSwitch_I	[W](R) The azimuth axis reached the hardware limit switch number one
107	ERR_azm_LimitSwitch_II	[W](R) The azimuth axis reached the hardware limit switch number two
108	ERR_azm_Soft_Limit_MAX	[W](C) The given target position for the azimuth axis was too large
109	ERR_azm_Soft_Limit_MIN	[W](C) The given target position for the azimuth axis was too small
110	ERR_Azm_bad_state	[P](R) Internal software error, wrong state detected
111	ERR_BAzm_bad_state	[P](R) Internal software error, wrong state detected
112	ERR_Azm_TopInstanze	[W](R) Internal state machine error
113	ERR_Azm_Oil	[W](C) The azimuth axis oil pump is not ready
114	ERR_e1v_FAULT	[W](C) The elevation axis controller raised an error message and the axis stopped moving

B LIST OF RS ERROR SYMBOLS

No	Text	Description
115	ERR_elv_ALARM	[W](C) The elevation axis controller raised a warning message but the axis will usually continue moving
116	ERR_elv_TIMEOUT	[W](R) The elevation axis controller did not respond to a request within the expected time
117	ERR_elv_Ref_FEHLER	[W](R) An error occurred during the referencing process of the elevation axis
118	ERR_elv_Parm_FEHLER	[W](R) An error occurred during the read-out of needed parameters from the elevation axis controller
119	ERR_elv_Etel_FEHLER	[W](R) The elevation axis controller is not in the correct state for the requested operation
120	ERR_elv_bad_state	[P](R) Internal software error, wrong state detected
121	ERR_elv_LimitSwitch_I	[W](R) The elevation axis reached the hardware limit switch number one
122	ERR_elv_LimitSwitch_II	[W](R) The elevation axis reached the hardware limit switch number two
123	ERR_elv_Soft_Limit_MAX	[W](C) The given target position for the elevation axis was too large
124	ERR_elv_Soft_Limit_MIN	[W](C) The given target position for the elevation axis was too small
125	ERR_Elv_bad_state	[P](R) Internal software error, wrong state detected
126	ERR_BElv_bad_state	[P](R) Internal software error, wrong state detected
127	ERR_Elv_TopInstanze	[W](R) Internal state machine error
128	ERR_Elv_Oil	[W](C) The elevation axis oil pump is not ready
129	ERR_Hilscher_Error	[W](R) The profibus controller could not be initialized correctly or didn't respond
130	ERR_Hilscher_Profibus	[W](R) The profibus communication failed
131	ERR_bad_type	[W](R) Internal software error, invalid, not implemented type used
132	ERR_Break_Error	[W](R) One brake did not work correctly
133	ERR_Break_Timeout	[W](R) One brake did not respond within the expected time

No	Text	Description
134	ERR_Axis_Mechanic_Blocked	? One axis is not movable due to a mechanic problem
135	ERR_Motor_has_bad_Polarity	? One axis motor is connected with the wrong polarity
136	ERR_Temp_Cabinet_HOT	[W](C) The temperature in the control cabinet is too high
137	ERR_Temp_Cabinet_COLD	[W](C) The temperature in the control cabinet is too low
138	W_RTMSTART	[I](C) The realtime module did start
139	W_RTMSTOP	[I](C) The realtime module did stop
140	W_DLGSTART	[I](C) The dialog program did start
141	W_DLGSTOP	[I](C) The dialog program did stop
142	W_TPLSTART	[I](C) The TCI TPL-Server did start
143	W_TPLConnectionLost	[W](C) A connection to the TCI TPL-Server was closed unexpectedly
144	W_TPLNewConnection	[I](C) A new connection was opened to the TCI TPL-Server
145	W_TPLSTOP	[W](C) The TPL-Server did stop
146	W_TPLTEST	[W](C) Warning for test purposes only
147	W_TPLREBOOT	[W](C) A reboot of the system was requested via TPL
148	W_TPLREBOOT_IGN	[I](C) A reboot of the system that was requested via TPL was ignored
149	W_DEFVAR	[W](S) The system could not find correct parameters and used a default set
150	W_BKPPAR	[W](S) The system could not find correct parameters and used a backup set
151	W_DEFPAR	[P](S) The system could not find correct parameters and used a default set
152	W_SYS_REBOOT	[P](C) A reboot of the system was initiated
153	W_SYS_HALT	[P](C) A halt of the system was initiated
154	ERR_not_def	[?](C) Default error message, not used

C Undocumented Modules

C.1 Module POINTING

This module provides functions to point the telescope to RA / DEC positions and is only available for the DIMM telescopes. It will be superseded by the much more advanced TSI functions and therefore removed in later releases.

The following functions are provided in this module:

Name	Type	Access	Description
TYPE	INT	RO	Type identifier, see below
VERSION	STRING	RO	Hardware version. Newer version may introduce new functionality
REVISION	STRING	RO	Hardware revision. Newer revision will not introduce new functionality
MODE	INT	RW	Pointing mode (0=internal, 1=use TRAJECTORY internally).
TARGET.RA	FLOAT	RW	Target RA.
TARGET.DEC	FLOAT	RW	Target DEC.
TARGETDISTANCE	FLOAT	RO	RMS Distance of all axes from the target.
TRACK	INT	RW	Start or stop tracking on RA/DEC position. Values are 0 to stop tracking; 1 to start tracking with positive zenith distance; 2 to start tracking with dead zone optimization, that is, if the telescope is capable of moving the second axis through the zenith, the software will use either negative or positive zenith distance values to avoid the azimuth position to run into a limit switch; 3 to start tracking with negative zenith distance; 4 to select automatically the zenith distance to minimize slewing time. After writing 2 or 4 the variable will either be 1 or 3 on readout, indicating which range was chosen.
POINTINGPARAMS	STRUCT	—	Contains pointing model coefficients (see below)
REFRACTION	STRUCT	—	Refraction correction settings.

The following pointing types are currently defined:

Type no	Description
0	Not available
1	Extra-solar object tracking only.

C.1.1 Pointing model parameters

This structure holds all pointing model coefficients. Unless noted otherwise, the units are degrees. The used pointing correction model is the standard geometrical model with 6 coefficients for mounting errors plus one for sagging of the tube due to gravitation. These coefficients can be calculated using standard numerical fitting technics or additional programs (e.g. TPoint) and are set by default to 0.

The following equations are used to calculate correction for azimuth and zenith axis:

$$\begin{aligned}
 d_A &= \sin A \cdot \cot Z \cdot c_{AN} \\
 &\quad - \cos A \cdot \cot Z \cdot c_{AE} \\
 &\quad + \cot Z \cdot c_{NP AE} \\
 &\quad - \frac{c_{CA}}{\sin Z} \\
 &\quad + c_{A OFF} \\
 d_Z &= \cos A \cdot c_{AN} \\
 &\quad + \sin A \cdot c_{AE} \\
 &\quad + \sin Z \cdot c_{FLEX} \\
 &\quad + c_{Z OFF}
 \end{aligned}$$

When pointing to RA/DEC values, the POINTING module will do the following steps:

1. Convert RA/DEC to AZ/ZD
2. apply refraction (if enabled)
3. apply pointing corrections as described above
4. add axis offsets if enabled by `CABINET.OFFSET_MODE`

The following values can be modified:

Name	Type	Access	Description
AOFF	FLOAT	RW	Absolut azimuth encoder offset.
ZOFF	FLOAT	RW	Absolut zenith distance encoder offset.
AE	FLOAT	RW	Azimuth axis tilt of vertical to NORTH.
AN	FLOAT	RW	Azimuth axis tilt of vertical to EAST.

Name	Type	Access	Description
NPAE	FLOAT	RW	Zenith distance axis not perpendicular to azimuth axis.
CA	FLOAT	RW	Telescope beam not perpendicular to zenith distance axis.
FLEX	FLOAT	RW	Flexure term.

C.1.2 Refraction parameters

The following values can be modified to control the refraction compensation:

Name	Type	Access	Description
MODE	INT	RW	0 - no refraction correction, 1 - use defaults for refraction (10 °C, 1010 mbar, corrected by height), 2 - use customized settings
TEMPERATURE	FLOAT	RW	Outside temperature in Celsius (only for mode 2).
PRESSURE	FLOAT	RW	Air pressure in mbar (only for mode 2).
HEIGHT	FLOAT	RW	Height above sea level in meters (only for mode 1).

C.2 Module SIMPLE_FOCUS

This module is provided as a quick patch for the DIMM telescope to allow unregulated Focus movements and will be removed in the future. The following functions are provided in this module:

Name	Type	Access	Description
STEP	FLOAT	WO	Switch power ON for the given value(in seconds), then stop the motor by switching the power OFF. If value is negative, the focus will run towards the inner position, else it will run to the outer position.
CURRPOS	FLOAT	RO	Since the Focus does not have a encoder, this will be 0 if it is in the innermost position, 1 if it is in the outermost position and 0.5 if somewhere in between.

D Abbreviations

Abbreviation	Description
TPL	Transfer Protocol Language
TCC	Telescope Control Computer, computer in cabinet, running the TCS
TCI	Telescope Control Interface, connection between TCS and TSS
TCS	Telescope Control System, software running on TCC
TSC	Telescope Software Computer, computer close to the telescope running TSS
TSI	Telescope Software Interface, connection between TSS and user applications interface or applications
TSS	Telescope Software System, software running on TSC

References

- [1] M. Ruder and D. Plasa. *TPL2, Transfer Protocol Language, V2 — A protocol for client-server based exchange of data and commands over a TCP/IP network connection*. 4pi systeme GmbH. 4PI-DOC-03-008-01.

